

The **Equalizer Block** is used to maintain tension on all legs of the sling during a lift. Rather than adjusting slings and hooks prior to completing a lift, the Equalizer Block will automatically adjust itself when load is put on the device from the sling. This product was designed specifically for Twin-Path® Extra Slings. Use only with Twin-Path® roundslings.



Part No. 1	Capacity (5:1 DF)	Maximum Sling Width (Inches)	Block Weight (lbs.)
SEB10	10 US ton	3	44
SEB25	25 US ton	4	79
SEB50	50 US ton	6	220
SEB75	75 US ton	8	270
SEB125M	125 metric ton	8	640



Use only with Twin-Path® slings. Synthetic Equalizer Block can fail if damaged, misused, overloaded, or improperly utilized. Inspect Synthetic Equalizer Block and Twin-Path® slings prior to use. Do not use a Twin-Path® sling that is wider than the stated maximum sling width for the size of the Synthetic Equalizer Block being utilized. Do not exceed rated capacity of the Synthetic Equalizer Block. Read and follow Manufacturer's Instructions before use. Use only if trained. Inspect before use. Death or Injury can occur from improper use or maintenance.

